

HULK ICF SYSTEM 3 STEP PROCESS



HULK SYSTEMS

LET'S NOT OVER-COMPLICATE THINGS!
THE BASIC APPLICATION OF THE HULK SYSTEM
CAN BE BROKEN DOWN INTO 3 EASY STEPS!

STEP 0

ENSURE YOUR FOAM IS CLEAN

You never want to spray over loose foam, dirt, or other contaminants and risk adhesion.

STEP 1

SPRAY LIQUID WATERPROOFING (HULK WP)

Spray a thick layer of the membrane on your wall. You'll know you're at 35-40mils once you see a bit of sag (product drip).

STEP 2

INLAY THE TEXTILE (HULK SRT)

Lay the textile into the still-wet section of wall you just sprayed. Smooth out any wrinkles.

STEP 3

SPRAY LIQUID WATERPROOFING AGAIN (HULK WP)

Immediately spray over the textile again. You'll know you've applied enough material, when the texture of the fabric is no longer visible.



Your Email



Your Phone Number



Your Address

